

FIG. 1
(Related Art)




FIG. 2

(Prior Art)

Notebook Mode

(Default Mode = Landscape Mode)




FIG. 3

(Prior Art)

Tablet Mode

(Default Mode = Portrait Mode)




FIG. 4
(Prior Art)






FIG. 5




FIG. 6

Notebook Mode
(User Set Mode = Portrait Mode)




FIG. 7

Tablet Mode

(User Set Mode = Landscape Mode)




FIG. 8




FIG. 9

